



1

POSITION THE FRONT AND RETURN BASE AS SHOWN BELOW, SO THAT THE CONNECTION POINTS WILL BE IN FRONT OF EACH OTHER




2

REMOVE ALL TRIMS EXCEPT FOR THE FRONT (MODESTY) TRIM.



7

LEVEL THE BASE USING THE LEVELERS UNDER EACH LIFTING COLUMN.



8

PLACE THE WORK SURFACES ON THE TOP FRAMES AND ALIGN THEM USING THE PILOT HOLES. PILOT HOLES SHOULD BE ALIGNED WITH END BRACKET HOLES. ALL WORK SURFACES ON ONE SIDE HAVE 3 PILOT HOLES AND ON THE OTHER SIDE ONLY 2. THE SIDE THAT HAS 3 PILOT HOLES WILL ALWAYS SIT TOWARD THE CONNECTION POINT OF THE WORK SURFACES AND THE SIDE THAT HAS 2 PILOT HOLES WILL SIT ON THE ENDS. MAKE SURE THERE IS A 3/4" GAP IN BETWEEN TWO WORK SURFACES.

